

SuperScreen 48" Set-Up Instructions

Banner heights
55" or 63" table top
84" floor



Included Components:

- 1) bag
- 2) telescopic poles
- 1) SuperScreen base
- 1) installed banner

Tips for raising & lowering banner into base:

- Be sure to hold top of banner tightly and not let go!
- Center banner into base to not damage banner edges!



Insert two poles into designated holes in base.



Using arrows on poles as a guide, extend top section of pole to line height indicator. Turn sections of pole to lock into place.



While holding pole steady, reach down for banner rail and begin raising the banner.

Tilt top banner rail down to insert in top of pole



While continuing to raise banner & holding pole, carefully lean banner stand back and hook top of banner to top of pole.



Complete!
You can now position the banner stand in the desired location.

AffordableDisplays.com 800.723.2050

Warranty Information:

The SuperScreen banner stand hardware & pole are covered under a 5 year warranty. Custom printed banner is covered for 90 days from order date. This warranty does not apply if the product has been damaged due to misuse and abuse, altered or used in ways or purposes it was not designed, or which have been damaged in shipping transit.

affordable
exhibit
displays inc