

# iPad Kiosk Portrait Set Up




## Product Parts

- 1- Stand body
- 1- iPad mounting holder
- 1- Base
- 1- Screws & Washers

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.


### Steps:

- 1) Attach front & back bases to the bottom of the stand with screws.
- 2) Attach the clam shell to the stand with hex nuts.
- 3) Insert iPad and feed wire through holes in stand.



When assembled

### Optional Cover for Home Button



- 1) Remove foam lining from inside bottom of clamshell as shown.
  - 2) Attach Home Button Shield with double-sided tape to inside of clamshell, keeping top of shield flush with clamshell opening as shown.
- NOTE:** This is a permanent fix and can't be easily removed.



- Tools Required:
- 1) Philips Screwdriver (included)
  - 2) Pliers

